

Duress events do not appear in Alarm Monitoring

Last Modified on 01/12/2022 1:58 pm EST

Symptom

When a duress code is entered at a reader, no events appear in the Main Alarm Monitor window in Alarm Monitoring.

No events appear regardless of whether the door was used.

Resolution

In System Administration:

- 1) From the **Monitoring** menu, select **Alarms**.
- 2) On the Alarm Definitions tab, ensure the **Display alarm** check box is selected for the following alarms in the list:
 - Granted Under Duress
 - Granted Under Duress, No Entry
 - Duress Access Grant
 - Duress Egress Grant

Applies To

OnGuard (All versions)

Additional Information

It is possible to have the **Display alarm** check box selected for only the following alarms, but these events will still not appear in the Main Alarm Monitor window in Alarm Monitoring:

- Duress Access Grant
- Duress Egress Grant

The additional alarms specified in the Resolution section must be set to be displayed for the events to appear.

