

How to update firmware on an LNVR or IntelligentVideo server

Last Modified on 01/13/2022 12:06 pm EST

How to update firmware on an LNVR or IntelligentVideo server

Procedure Steps

- 1) Stop all Lenel services on the LNVR or IntelligentVideo server.
- 2) Copy the new firmware to the LNVR or IntelligentVideo server, and open **setup.exe** from the firmware installation folder.
- 3) If prompted to install prerequisite software such as MSXML 6 or .NET Framework 3.5, choose to install this software. Reboot the computer if prompted, then click the [Upgrade] button when the LNVR installer resumes.
- 4) Read the license agreement. If you agree to the terms of the license, select the appropriate radio button and click [Next].
- 5) Click [Install] to begin installation of the new firmware.
- 6) The Lenel Video Suite Tool is displayed. Verify that the default selections for the storage, security, and identity settings are correct. Make any required changes and click [Next] for each step of the tool.
- 7) Click [Finish] to exit the Lenel Video Suite Tool.
- 8) The Security Utility is displayed. Follow the on-screen instructions and click [Apply] to make the suggested changes.
- 9) The Security Utility must be run whenever a change is made to the operating system or the software. Click [OK] to acknowledge this message and [Close] to exit the Security Utility.
- 10) Click [Finish] to exit the firmware installer.

Applies To

LNVR (All versions)

IntelligentVideo (All versions)

Additional Information

None

