

# How to assign individual cameras to a Monitor Zone

Last Modified on 05/22/2025 9:57 am EDT

How to assign individual cameras to a Monitor Zone

## Procedure Steps

In System Administration:

- 1) From the **Monitoring** menu, select **Monitor Zones**.
- 2) Click [Add] and then type a **Name** for the monitor zone.
- 3) From the **Select** drop-down, select "Video Recorders."
- 4) In the device listing window below, select one or more video recorders to add to the monitor zone.  
**Note:** Selected recorders are indicated by a check mark.
- 5) From the drop-down below, select "Specify Child Devices Individually."
- 6) Click [Assign]. The list on the right now includes the video recorder.
- 7) From the **Select** drop-down, select "Cameras." The device listing window below now includes cameras for the video recorders in the monitor zone.
- 8) Select any of the cameras you want to add to the monitor zone, and then click [Assign].  
**Note:** Selected cameras are indicated by a check mark.
- 9) Click [OK] to save the monitor zone.

## Applies To

OnGuard (All versions)  
LDVR (All versions)  
LNVR (All versions)

## Additional Information

For more information, refer to the Monitor Zones Folder chapter in the System Administration User Guide.

