

How to reset a Cobox Micro

Last Modified on 12/21/2021 1:19 pm EST

How to reset a Cobox Micro

Procedure Steps

- 1) Press and hold the reset button.
- 2) Continue to hold the button down while powering off the board.
- 3) Continue to hold the button down while powering on the board.
- 4) Continue to hold down the button until the board LEDs light up.
- 5) Release the reset button.

Applies To

OnGuard (All versions)

Additional Information
