

What Ports are Used by OnSSI NetEVS?

Last Modified on 12/28/2021 1:34 pm EST

Question

What ports are used for OnSSI NetEVS?

Answer

Ports Used for NetEVS

Ocularis Base Port Requirements

- IIS PORT: 80 Inbound
- IMAGE SERVER PORT: 7563 Inbound/Outbound
- MESSAGE QUEUING PORT: 1801 Inbound/Outbound

NetEVS Management Port Requirements

- IIS PORT: 80 Inbound
- COMMUNICATION WITH FAILOVER SERVERS 8844, 11000 Inbound/Outbound
- COMMUNICATION WITH RECORDING SERVERS 9993 Inbound/Outbound
- MESSAGE QUEUING PORT 1801 Outbound

NetEVS Recorder Port Requirements

- IMAGE SERVER PORT: 7563 Inbound
- CAMERA SPECIFIC PORTS: 80, 21,25, 554, 1024, 5432 Inbound/Outbound (Depends on manufacturer)
- COMMUNICATION WITH MANG. SERVERS: 8844, 9993, 11000 Inbound/Outbound

Ocularis Client Port Requirements

- CONNECTION TO OCULARIS BASE IIS Port: 80 Outbound
- VIDEOWALL PORT: 9010 Inbound/Outbound
- IMAGE SERVER PORT: 7563 Inbound/Outbound
- MESSAGE QUEUING PORT: 1801 Inbound/Outbound
- VIDEO PUSH PORT: 7007 Inbound/Outbound
- PTZ CONTROL COMMANDS: 7563 Inbound/Outbound

Applies To

NetEVS

Additional Information

None
