

Configuring Pass-Thru Format in VeriAdmin

Last Modified on 06/02/2025 2:20 pm EDT

Configuring Pass-Thru Format in VeriAdmin

Procedure Steps

1. In VeriAdmin, go to the **Unit parameter settings**, and then select the Wiegand tab.
2. Select the **Pass-Thru** format.
3. Select **Custom** from the drop down.
4. Enter the **Total Bits**.
5. Enter **0** for the **ID Start Bit**.
6. Enter the total number of bits for the **Num ID Bits**.

For example, enter a 37-bit format as:

- **37** for the **Total Bits**
- **0** for the **ID Start Bit**
- **37** for the **Num ID Bits**

Applies To

VeriAdmin

Additional Information
