

# Where do you disable the ability for a user to give an "Allow 1 free APB pass" in Alarm Monitoring?

Last Modified on 01/07/2022 3:38 pm EST

## Question

Where do you disable the ability for a user to give an "Allow 1 free APB pass" in Alarm Monitoring?

## Answer

The ability for an OnGuard user to give an "Allow 1 free APB pass" in Alarm Monitoring is controlled by the **Badge Modify** permission.

Badge Modify location:

**Users > Cardholder Permissions Group > Badge > Modify.**

Unchecking the Modify box removes the ability for that user to give an "Allow 1 free APB pass" in Alarm Monitoring.

## Applies To

OnGuard (All versions)

## Additional Information

---