

How to add a Guardall panel to OnGuard?

Last Modified on 01/07/2022 3:39 pm EST

How to add a Guardall panel to OnGuard?

Procedure Steps

1. Install the latest 6.4.500 TU1 + HF that includes the latest modifications for the Guardall panels.
2. In system administration, navigate to **Additional Hardware > Intrusion Devices**.
3. Add the Guardall panel and configure the following fields:
 - a. Location
 - i. Workstation: name of computer where the Comm Server is running
 - ii. Panel type
 - b. Connection:
 - i. IP: Address of the panel
 - ii. Port: usually 6000
 - c. Options:
4. MARK THE PANEL OFFLINE
5. On the Guardall PX config tab and configure the following fields :
 - a. GSR:
 - i. Serial Number S/N
 - ii. GSR ID
 - iii. IP of the Comm Server (where panel is connected to)
 - b. Panel IP
 - c. Gateway
 - d. Subnet
6. Mark the panel ONLINE.

Applies To

OnGuard (All versions)

Additional Information

