

# Configuring Custom IP for Elevator Dispatch

Last Modified on 06/06/2025 3:21 pm EDT

Otis Compass V3

## Procedure Steps

OnGuard 7.3.345 is the first version of OnGuard to allow a custom IP address to be configured for the Elevator Dispatch with Otis Compass V3.

1. Backup the ACS.ini file.
2. Open Notepad as Administration.
3. Click File > Open and browse to the live copy of the Acs.ini file.
4. On a blank line, add in an [Otis] section (including the brackets).
5. Add the following settings under [Otis]:

DESHeartbeatAddress= 234.46.30.7

SecuritySystemIPAddress = IP Address Of Commuication Server

HeartbeatThreadTTL= 10

## Applies To

Otis Compass V3

## Additional Information

Be sure to update the terminal addresses as need. The last two octets of the IP address make up the terminal address.

---