

Linkage issue when using Advisor Advanced DGP output

Last Modified on 04/08/2025 12:48 pm EDT

Symptom

Linkage issue when using Advisor Advance DGP output. When using a DGP output, the activation status to build a global I/O that changes the reader mode (for example, to Unlocked) provides good **output**, but the **linkage** is not executed. The same action with an **output** located on the **Advisor Advanced** Board functions correctly.

Resolution

None. This is not a supported configuration. This functionality is not supported by either **Advisor Advanced** or from OnGuard.

Applies To

OnGuard 7.6 and later

Additional Information

© 2024 Honeywell International Inc. All Rights Reserved.
